

GasRam Installation on Armored Vehicle

Most agency's use the Magnum Ram with a receiver welded on.

A 2" X 10' boom is used, supplied with any Ram ordered with a 2" hitch, 2 probes, one 5" disk, a lanyard guide and hitch pin. If you purchase the boom it comes with a front and rear attachment that can be welded to the truck to store when not in use.

A standard 2" trailer hitch is mounted in the front of Vehicle and should be reinforced to main frame, a 10 degree angle is the Maximum that should be applied to the boom, and this angle gives the driver a straighter insertion into the building and gives the driver a view of the boom and Ram.